

USE IN CASE OF FIRE

Easy Directions: **FIRST CALL 911**



1
Hold can upright
and break off tab



2
Hold can 3 to 4
feet from fire



3
Spray across base
of fire using gentle
sweeping motion

Easy to Use:

- No need to shake can.
- Hold can upright and spray.
- Discard after use.

Easy Clean Up:

- Simply wipe area with damp cloth.
- No messy residue.
- Will not damage boat or auto parts.

CAUTION: CONTENTS UNDER PRESSURE. DO NOT PUNCTURE OR INCINERATE CONTAINER, EVEN WHEN EMPTY. DO NOT EXPOSE TO HEAT OR STORE AT TEMPERATURES ABOVE 120°F/49°C. AVOID FREEZING. STORE BETWEEN 32°-104°F / 0°-40°C. IF DROPPED OR DAMAGED DISCARD AND REPLACE. CONTENTS MAY CAUSE SKIN IRRITATION. PROTECT HANDS DURING CLEAN UP. NOT INTENDED TO REPLACE AN NFPA 10 COMPLIANT FIRE EXTINGUISHER WHERE REQUIRED.

WARNING: NON-REFILLABLE. USE ALL CONTENTS, DISCARD AFTER USE. DO NOT ATTEMPT TO FIGHT LARGE FIRES THAT ARE TOO DIFFICULT TO FIGHT SAFELY FROM 3 TO 4 FEET. ENSURE A SAFE PATH OF ESCAPE IN THE EVENT OF FAILURE TO STOP THE FIRE. MAY NOT OPERATE AFTER EXPIRATION DATE. STORE IN ORIGINAL CONTAINER IN AREA INACCESSIBLE TO SMALL CHILDREN.

FIRST AID: EYES: Flush with water for at least 15 minutes. If irritation persists, call physician. SKIN: Flush with water for at least 15 minutes. If irritation persists, call physician. INGESTION: Do not induce vomiting. Call physician immediately.

- Meets or exceeds D.O.T.-2Q requirements
- Pressured with non-flammable propellant

KEEP OUT OF REACH OF CHILDREN