



Self-Opening Kitchen Shears

PKS-1

These Self Opening Kitchen Shears have large comfortable handles are sprung to automatically reopen after each cut.

HOW TO USE

Unlock the red safety catch. Gently squeeze the scissors to cut through food, packets etc. If required wash with warm soapy water and allow to dry and then squeeze handles together to re-lock to keep safe when not in use.



PKS	FEATURE	BENEFITS
1	Large comfortable ergonomic handle	Allows strength of whole hand to be used
2	Stainless steel spring	Automatically reopens after each cut
3	Serrated blade	Grips item being cut
4	Safety catch to keep closed when not in use	Keeps closed when not in use



A good pair of kitchen shears have endless uses, from opening packaging or chopping food to snipping herbs. Some people find it an easy way to cut pizza too!

RECOMMENDED FOR



Weak Grip



Poor Hand Control